

INSTALLATION INSTRUCTIONS

FOR ITEM 193416 48" Sq Kitzil Cilindro Pendant

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. 48" SQ FIXTURE FRAME
2. 42"W x 30"H FABRIC SHADE
3. 42"W ACRYLIC DIFFUSER
4. CANOPY ASSEMBLY
5. 144" CHAIN

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Collar from Canopy Assembly to release Crossbar, Brass Loop, & Quick Link. FIG A.
3. Mount Crossbar to structure ensuring that connection is suitable for minimum 80lbs and that Electrical Line Wires remain accessible.
4. Remove Bolts and Acorn Nuts from Spider on Fixture Frame.
5. Attach Shade to Spider using Bolts and Acorn Nuts with Shade Tabs on bottom of Spider. FIG B.
6. Unravel Lead Wire and Safety Cable from top of Fixture Frame.
7. Attach desired length of Chain to Quick Link at top of Fixture Frame.
8. Run Fixture Lead Wire and Safety Cable up Chain. It is recommended to weave through every 3rd Link of Chain.
9. Slide first Screw Collar and then Canopy over Chain and Wire and let rest on top of Fixture Frame.
10. Attach loose end of Chain to Quick Link on Brass Loop/Crossbar.
11. Feed Fixture Lead Wire through Crossbar Loop and make electrical connection to Structure Line Wires following all Local Codes and Procedures.
12. Feed Safety Cable through Crossbar Loop and secure to Structure ensuring that connection is suitable for minimum 80lbs.
13. Slide Canopy and Screw Collar up Chain and thread Screw Collar onto Nipple until top of Canopy is flush with ceiling.
14. Install 6 Medium Base 40Watt Bulbs(not included) into Sockets.
15. Remove Finial from bottom of Fixture.
16. Slide Acrylic Diffuser onto Threaded Rod at bottom of Fixture and set inside lip of Shade, but below Tabs.
17. Secure bottom Diffuser with Finial. FIG C.
18. Remove plastic from Shade.
19. Power on and ENJOY!!!

