

# INSTALLATION INSTRUCTIONS

FOR CASTILLA 21LT THREE TIER CHANDELIER 115048

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

A1 TOP TIER	1/4-20 BOLTS (QTY 12)	FIBER DRIP CANDLE COVERS (QTY 21)
A2 CENTER TIER	1/4-20 NUTS (QTY 12)	
A3 BOTTOM TIER	3/4-6/32 SET SCREW (QTY 12)	
1/4-20 ACORNS (QTY 9)	CANOPY ASSEMBLY	
STEEL UPRIGHTS (QTY 12)	CHAIN 120"	

**Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Suspend A3, Bottom Tier, off of the floor on scaffold. Center rod with plate should be facing up.
3. Move A2, Center Tier, into position to combine with A3. Remove and save 1/4-20 Acorn nuts from studs extending out of bottom-center hub of A2. Connect electrical Molex plugs between A2 and A3.
4. Set A2 onto A3 so that 1/4-20 studs from A2 slide down through holes in center plate of A3. Reattach Acorn nuts and secure.
5. Move A1, Top Tier, into position to combine with A2. Remove and save 1/4-20 Acorn nuts from studs extending out of bottom-center hub of A1. Connect electrical Molex plugs between A1 and A2.
6. Set A1 onto A2 so that 1/4-20 studs from A1 slide down through holes in center plate of A2. Reattach Acorn nuts and secure.
7. Remove nuts from studs on top hub cap at of A1 and remove cap.
8. Begin attaching Steel Uprights to fixture. Move uprights into position with pinched ends up. Bottom of uprights will set onto metal tabs on inside of ring of A3. Bottom of upright is secured to metal tab by screwing 3/4-6/32 set screws down through uprights and into metal tabs.
9. Top, pinched ends of uprights, will attach to top hub of A1. Feed 1/4-20 bolt through uprights and into hub. Secure bolts inside hub, with 1/4-20 nuts.
10. Once all uprights have been secured, reattach hub cap at top of A1.
11. Dissassemble canopy assembly by removing 8-32 Acorn nuts from studs extending through canopy. Slide mounting plate with welded loop and attached quick link out of canopy.
12. Secure canopy mounting plate to ceiling, ensuring that connection is suitable for minimum of 210lb load and that electrical supply wires are accesible.
13. Attach desired length of chain to quick link on loop at top hub of A1.
14. Slide canopy over chain and let rest on hub at top of A1.
15. Fixture can now be hung. Attach chain to quick link on welded mounting plate loop.
16. Run electrical wires and safety cable from top hub of A1 up through every 3rd link of chain.
17. Make electrical connections to supply power following local codes and procedures. Secure safety cable to structure ensuring connection is suitable for minimum 210lb load.
18. Slide canopy up chain and over mounting plate. Reattach 8-32 Acorn nuts to studs extending through canopy and secure.
19. Place fiber drip candle covers onto sockets on arms.
20. Install 21-Candelabra 60Watt bulbs(not included) into sockets on arms.