

FOR ITEM 116372 53" LONG NEO 6 LIGHT POT RACK



This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

FIXTURE COMPONENTS

1. CANOPY W/ WIRE ACCESS PANEL
2. 4X 60"L OF CHAIN
3. FRAME
4. 10 X SLIP ON POT HOOK
5. 10 X S SLIP ON POT HOOK

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the Acorn Nuts & Nuts from the bottom of the Canopy to release the M-plate.
3. Using Customer Supplied Hardware, affix the M-plate directly to the J-box ensuring the connection is suitable for a minimum of 50 lbs. and that electrical supply wires remain accessible.
4. Lift the Canopy with the Chain and Frame. Attach to the M-plate and secure in place using the Acorn Nuts & Nuts from before.
5. Unscrew the Brass Knob at the bottom of the Canopy to remove the Wire Access Panel.
6. Following all local codes and procedures, make electrical wire connections from Supply wires to Fixture Lead wires.
7. Push wire up into Canopy and put the Wire Access Panel back in place.
- 8.
9. Remove the Cork Washer and Uno Ring from each Socket.
10. Carefully lift each Shade (one at a time) up to the Frame and secure in place by sliding the Cork Washer on and screwing in the Uno Ring around each Socket.
11. Install 6x 60W E12 BA9 Bulbs (not included) into Sockets.
12. Power on and ENJOY!!!

