

INSTALLATION INSTRUCTIONS

FOR ITEM 118380 Palisade Wall Sconce

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SCNCE HARDWARE
2. 27.5" x 10" GLASS PANEL
3. 20.5" x 3.5" GLASS PANEL (QTY 2)
4. 10" x 3.5" GLASSS PANEL

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Sconce Hardware to release Universal Crossbar with Studs.
3. Attach Universal Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 25lbs and that Electrical Supply Wires remain accessible.
4. Following All Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Hang Sconce Hardware by sliding it onto Crossbar Studs and secure it with Brass Balls.
6. Install 2 E26 60Watt Bulbs(not included) into Sockets.
7. Slide 20.5" x 3.5" Glass Panels into channels on left and right sides of Sconce Hardware.
8. Slide 10" x 3.5" Glass Panel into top channel of Sconce Hardware.
9. Slide 27.5" x 10" Glass Panel into front channel of Sconce Hardware.
10. Power on and ENJOY!!!

