

INSTALLATION INSTRUCTIONS

FOR ITEM 120215 INDIGO WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SHADE
2. LAMPHOLDER (QTY 2)

Caution:

**Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Knobs from Lampholder to release Universal Crossbar with Studs. Reserve Knobs.
3. Affix Crossbar to Junction Box ensuring connection is suitable to hold a minimum of 25lbs and that Electrical Supply Wires remain accessible.
4. Following All Local Codes and Procedures, make Electrical Connection from Lead Wires to Supply Wires.
5. Slide Lampholder over Crossbar Studs and secure with Reserved Knobs.
6. Follow Steps 2-5 for 2nd Lampholder.
7. Install 4-E26 60Watt Bulbs(not included) into Sockets.
8. Install Customer Supplied Mounting Screws into wall ensuring they will hold a minimum of 25lbs and align with Shade Mounting Slots.
9. Hang Shade from Mounting Screws.
10. Power on and ENJOY!!!

