

# INSTALLATION INSTRUCTIONS

FOR ITEM 120771 (13" Wide Slenderleaf 2 Light Wall Sconce)

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. BACKPLATE
2. MOUNTING PLATE W/ STUDS
3. FRAME
4. CANDLE COVER
5. SHADE

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the Brass Balls at the front to release a Mounting Plate w/ studs from Backplate, save it for later.
3. Using Customer supplied hardware, affix the Mounting Plate w/ studs directly to the J-Box, ensuring the connection is suitable for a minimum of 7 lbs. and that electrical supply wires remain accessible.
4. Following all local codes and procedures, make electrical wire connections from supply wire to fixture lead wires.
5. Lift the Frame to the Wall and protrude the Studs through Backplate.
6. Resecure Frame to the Wall with the Brass Balls from before
7. Slide Candle Cover over Sockets.
8. Install 2X 40W E12 BA9 (not included) into sockets.
9. Install Shades over the Bulb.
10. Power On and Enjoy!!!

