

INSTALLATION INSTRUCTIONS

FOR ITEM 293216 (9" Wide Moravian Star Wall Sconce)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Fixture Components

1. SCONCE ASSEMBLY

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew Acorn nuts and Nuts at the front to release a M-plate with Studs from Backplate, save it for later use.
3. Using Customer Supplied hardware, affix the M-plate to wall, ensuring the connection is suitable for a minimum of 45 lbs. and that electrical supply wires remain accessible.
4. Following all local local codes and procedure, make electrical wire connections from supply wire to fixture lead wires.
5. Lift the Frame to the Wall and protrude the Studs through Backplate.
6. Resecure Frame to the Wall with the Acorn nuts and Nuts from before.
7. Onscrew Brass ball on front to open Relamping Door.
8. Install 60W E26 A23 Bulb (not included) into the Socket.
9. Close the Relamping Door. Resecure Brass Ball.
10. Power on and ENJOY!!!

