

INSTALLATION INSTRUCTIONS

FOR ITEM 133483 (11"W Sunflower 2 LT Wall Sconce)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SHADE
2. MOUNTING PLATE W/ STUDS
3. FRAME

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the Balls at the front of the Frame to release the Mounting Plate.
3. Using customer supplied hardware, affix the Mounting Plate directly to the J-Box, ensuring the connection is suitable for a minimum of 10 lbs. and that electrical supply wires remain accessible.
4. Following all local codes and procedures, make electrical wire connections from supply wire to fixture lead wires.
5. Re-secure the Frame onto the Mounting Plate using the Balls from before.
6. Slide the Candle Covers over the Sockets.
7. Install 2x 40W E12 B10 Bulbs (not included) into Sockets.
8. Power on and ENJOY!!!

