## INSTALLATION INSTRUCTIONS

FOR ITEM 134178 Forestwood Pendant



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution**: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

- 1. CANOPY ASSEM, BLY
- 2. 36" CHAIN
- 3. SHADE

## Caution:

## Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Unscrew Canopy Nut to release Crossbar with Loop.
- 3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 10lbs and that Supply Wires remain accessible.
- 4. Attach desired length of Chain to Shade Loop.
- 5. Weave Lead Wires through every 4th Link of Chain.
- 6. Slide Canopy Nut and Canopy over Chain and Wire and allow them to rest on top of Shade.
- 7. Attach loose end of Chain to Crossbar Loop.
- 8. Feed Lead Wires through Crossbar Loop and Following All Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
- 9. Slide Canopy up Chain to ceiling and secure with Canopy Nut.
- 10. Install 3-E26 60Watt Bulbs(not included) into Sockets.
- 11. Power on and ENJOY!!!

