INSTALLATION INSTRUCTIONS

FOR ITEM 134526 AELLO WALL SCONCE



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. STAINED GLASS SHADE
- 2. BACKPLATE

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Shade by unscrewing Nuts from Shade Crossbar at top of Backplate.
- 3. Separate Universal Crossbar with Fixture Mounting Studs from Backplate by unscrewing Nuts from either side of Sockets.
- 4. Attach Universal Crossbar to J-Box with Fixture Mounting Studs facing out and ensuring that Structure Line Wires remain accessible.
- 5. Connect Fixture Lead Wires to Structure Line Wires following all Local Codes and Procedures.
- 6. Slide Backplate over Studs on Crossbar and screw Nuts onto Studs to secure.
- 7. Install 2 Medium Base 60Watt Bulbs(not included).
- 8. Slide Shade Crossbar onto Studs at top of Backplate and secure with Nuts.
- 9. Power on and ENJOY!!





