

INSTALLATION INSTRUCTIONS

FOR ITEM 144909 CILINDRO TEXTRENE PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. PENDANT HARDWARE
2. SHADE
3. DIFFUSER

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy to release Crossbar with Studs.
3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold minimum of 10lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
5. Hang Pendant Hardware by sliding Canopy onto Crossbar Studs and secure with Brass Balls.
6. Loosen Knurled Nut above Socket and slide Shade connector into gap. Secure by tightening Knurled Nut.
7. Install 1-E26 60Watt Bulb(not included) into Socket.
8. Insert Diffuser into bottom of Shade and allow it to rest on Shade Lip.
9. Power on and ENJOY!!!

