

INSTALLATION INSTRUCTIONS

FOR ITEM 146812 6" WIDE COACHMAN WESTMINSTER SCNCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SCNCE ASSEMBLY
2. CANOPY

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the Brass Balls on the Backplate to release the Crossbar.
3. Using Customer supplied hardware, affix the crossbar directly to the J-Box ensuring the connection is suitable for 10 lbs. and that electrical supply wires remain accessible.
4. Following all local codes and procedures, make electrical wire connections from supply wires to fixture lead wires and secure the Frame to the Crossbar with the Brass Balls from before.
5. Install 1X 60W E26 A19 bulb (not included) into socket.
6. Power on and ENJOY!!!

