

INSTALLATION INSTRUCTIONS

FOR ITEM 150873 WOLF AT DAWN MINI PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 72" CHAIN
3. SHADE

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Knurled Nut from Canopy Assembly to release Crossbar with Loop.
3. Using Customer Supplied Fasteners, attach Crossbar to Junction Box ensuring connection is suitable to hold 10lbs and that Electrical Supply Wires remain accessible.
4. Attach desired length of Chain to loop on Shade.
5. Weave Lead Wire through every 3rd Link of Chain.
6. Slide Knurled Nut and then Canopy over Chain and Lead Wire and allow them to rest on top of Shade.
7. Hang Fixture by connecting loose end of Chain to Crossbar Loop.
8. Feed Lead Wires through Channel in Crossbar Loop.
9. Following all Local Codes and Procedures, make electrical connection from Lead Wires to Supply Wires. Smooth Lead Wire connects to Line Supply Wire. Ribbed Lead Wire connects to Neutral Supply Wire.
10. Slide Canopy and Knurled Nut up to ceiling and secure Canopy by threading Knurled Nut onto Crossbar Loop.
11. Install 1 Medium Base 60Watt Bulb(not included) into Socket.
12. Power on and ENJOY!!!

