



- 1.) Attach cross bar(A) to j-box using customer provided screws.
- 2.) Unscrew acorn nuts(J) from shade tabs(K), remove shade(L) from spider (I) and set aside.
- 3.) Unravel electrical cord(G) and steel cable(F) and feed through center hole on top diffuser(H). Slide diffuser down cables, flush with spider(I).
- 4.) Determine desired overall height.
- 5.) Insert steel cable(F) through cable gripper(D) and electrical cord(G) through canopy(C).
- 6.) When at desired length, tighten cable gripper(D), and crimp metal strain relief to electrical cord above canopy.
- 7.) Trim excess cable/cord.
- 8.) Wire as per local electrical codes.
- 9.) Secure canopy(C) to cross bar(A) by tightening canopy nuts (E) onto cross bar screws(B).
- 10.) Install light bulbs.
- 11.) Attach shade tabs(L) to spider(I) using acorn nuts (J).



visit us on the web at www.meyda.com