

INSTALLATION INSTRUCTIONS

FOR ITEM 156359 (11" Wide Wedge Wall Sconce)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CROSSBAR W/ STUDS
2. BACKPLATE
3. SHADE
4. SCREWS (QTY.- 2)
5. BRASS BALLS

Caution:

Be sure power is off at the main breaker box prior to installation.

Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is on hand
2. Unscrew the screws on Top and Bottom of the shade to release the Backplate from the Shade.
3. Unscrew the Balls at the front of the backplate to release the Crossbar.
4. Using customer supplied hardware, affix the Crossbar directly to the J-Box, ensuring the connection is suitable for a minimum of 15 lbs. and that electrical supply wires remain accessible.
5. Following all local codes and procedures, make electrical wire connections from supply wire to fixture lead wires.
6. Re-secure the Backplate onto the Crossbar using the Brass Balls from before.
7. Install 1x 60W E26 T10 Bulb (not included) into Socket.
8. Slide Shade back in the place and secure it using screws from before.
9. Power on and ENJOY!!!

