

INSTALLATION INSTRUCTIONS

FOR MUIRFIELD WALL SCONCE 156674

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove shade from fixture by unscrewing brass screws from studs on top of backplate.
3. Unscrew brass balls from face of backplate and detach universal crossbar.
4. Attach universal crossbar to J-Box ensuring that electrical supply wires are accessible.
5. Following local codes, connect fixture to electrical supply wires from J-Box.
6. Align holes on backplate of fixture to studs extending from Universal Crossbar and attach. Screw brass balls onto studs until tight.
7. Install 2-Candelabra 40Watt Bulbs(not included) into sockets.
8. Mount shade and reattach brass screws to top of backplate.

