

ASSEMBLY INSTRUCTIONS FOR #158958

G = glob
 | = strip of silicone



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1) Remove any old silicone from inside shade.
- 2) Begin by inserting the top of the glass into the top bent metal tabs made for holding the glass in place. You will not be bending the tabs.
- 3) Once the glass is to the top and flush with the shade walls, you will have the glass slide down into the bottom bent metal tabs.
- 4) When the glass was first installed the fixtures were on their sides. The craftsman would install half the shade's glass, let it dry overnight. Then finish the other half the next day.
- 5) We used clear silicone. To silicone the glass in place the craftsman would put a glob at the each of the four corners of the glass and two strips on either side of the glass pane. (See fig.1) The next panes of glass should squish into these globs and the craftsman would run his finger along the two strips that he laid.
- 6) When finishing the next half you may need to cut away some of yesterday's silicone to fit rest of glass. Then re-apply silicone to make secure. Run your finger along the strips to smooth out and push in the silicone.
- 7) Let it dry. You are finished.

Glass Installation

2ND AVE.™



LIGHTING

"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-843-1602

MONDAY - FRIDAY 8:00 a.m. - 6:00 p.m. ET

visit us on the web at www.2ndave.com