

INSTALLATION INSTRUCTIONS

FOR ITEM 165867 MADISON SEMI FLUSHMOUNT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- A. 48"W WHITESTONE IDALIGHT BOWL
- B. CANOPY W/ DOWNROD AND LIGHT CLUSTER
- C. SUPPORT ARM W/CONNECTION HARDWARE (QTY 6)
- D. FINIAL ASSEMBLY

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Balls from bottom of Canopy to release Universal Crossbar with Studs.
3. Attach Universal Crossbar to J-Box with Studs facing down and ensuring that Electrical Supply Wires remain accessible.
4. Make electrical connection from Fixture Lead Wires to Structure Supply Wires following all Local Codes and Procedures.
5. Slide Canopy over Studs on Crossbar and secure with Balls.
6. Hang Support Arms from Canopy Hooks with Connection Hardware at bottom of Arms.
7. Unscrew Half Balls from Connection Hardware.
8. To attach Bowl, feed Nipples from Connection Hardware through holes in Bowl. Secure with Half Balls on the outside of Shade.
9. Unscrew Ball from Finial Assembly to release Finial.
10. Attach Finial by feeding Nipple with Nut and Washer on inside through hole in Center-Bottom of Bowl. Butt Finial up to bottom of Bowl and secure with Ball.
11. Install 8 Medium Base 40Watt Bulbs(not included).
12. Power on and ENJOY!!!

