

INSTALLATION INSTRUCTIONS

FOR TOP DIFFUSER OF BANCROFT 2 LT WALL SCONCE 169041

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. FABRIC SHADE
2. WHITE ACRYLIC DIFFUSER
3. BUTTON HEAD SCREW

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. If Diffuser is already installed, remove Button Head Screw and Diffuser.
2. Replace Diffuser on top of Shade ensuring that Diffuser is seated **BELOW** top Structural Frame Bar, but **ON TOP** of Pegs and Button Head Screw Receptacle.
***** To install Diffuser properly, make certain that the frosted side is facing up. This will allow Button Head Screw to set inside Recessed Pilot Hole in Diffuser when installed.**
3. Fasten Diffuser to Shade by installing Button Head Screw through Diffuser into Button Head Screw Receptacle.
***** If hole in Diffuser does not line up with Receptacle, begin threading Screw into Receptacle at an angle until holes align.**
***** If Screw does not seat flush with top of Diffuser once installed, ensure that Recessed Pilot Hole in Diffuser is facing up.**

