

INSTALLATION INSTRUCTIONS

FOR ITEM 170994 NELSON OBLONG PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
 2. Remove Hex and Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts.
 3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 60lbs and that Electrical Supply Wires remain accessible.
- This item is designed to have a 126" overall drop from the ceiling. If lesser drop is desired, cut length from the single hole end of the Rod. Once the Rod has been cut, drill a 1/4" Hole, 5/16" from the cut end.**
4. Feed Fixture Lead Wires through double hole end of the Rod and slide Rod over Cylinder at top-center of Shade Frame.
 5. Secure Rod to Shade Frame with provided Bolts, Hex, and Acorn Nuts.
 6. Feed Lead Wire through Canopy and slide Canopy onto Rod and let it rest on top of Shade Frame.
 7. Feed Spring Pin through hole at top of Rod.
 8. Slide Canopy up Rod allowing Spring Pin to rest in Timing Plate inside Canopy at the desired hanging orientation.
 9. Lift Fixture up to ceiling allowing Mounting Plate Studs to pass through Canopy. Secure with reserved Nuts.
 10. Remove Screws from Canopy Cover Plate and lower Cover Plate.
 11. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
 12. Slide Cover Plate back up to Canopy and secure with Screws.
 13. Install 6-E26 60Watt Bulbs(not included) into Sockets.
 14. Power on and ENJOY!!!

