

INSTALLATION INSTRUCTIONS

FOR ITEM 177107 Paramount Pendant

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. PENDANT BODY

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Acorn Nuts for later use.
3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 50lbs and that Electrical Supply Wires remain accessible.
4. Attach desired length of Chain to Quick Link at top of Pendant Body.
5. Weave Pendant Lead Wires through every 4th Link of Chain.
6. Slide Canopy over Chain and Lead Wire and allow it to rest on top of Pendant Body.
7. Hang Fixture by connecting loose end of Chain to Quick Link on Mounting Plate Loop.
8. Slide Canopy up Chain and feed Lead Wire through Wire way.
9. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
10. Slide Canopy up to ceiling, over Mounting Plate Studs, and secure with reserved Acorn Nuts.
11. Remove Ball and Cap at bottom of Fixture.
12. Install 3-E26 12Watt LED Bulbs(not included) into Sockets.
13. Replace bottom Cap and secure with Ball.
14. Power on and ENJOY!!!

