

# INSTALLATION INSTRUCTIONS

FOR THORNDIKE 15 LT TWO TIER CHANDELIER 177277

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 60" CHAIN
3. HUB WITH ATTACHED SAFETY CABLE AND ELECTRICAL WIRE
4. 23.5" ARMS (QTY 7)
5. 23.5" ARMS WITH WIRE (QTY 3)
6. 5 LT TOP TIER BODY
7. 10 LT BOTTOM TIER BODY
8. 1"W x 6"H FIBER DRIP CANDLE COVERS (QTY 15)

**Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.

2. Unscrew, remove and set aside Collar from Canopy Assembly.

3. Separate Canopy Mounting Plate with attached Loop from Canopy. Set Canopy aside.

4. Affix Mounting Plate with Loop to ceiling ensuring that connection is suitable for a minimum of 90lbs. Make certain that electrical lead wires remain accessible.

5. Attach desired length of Chain to Loop on top of Hub.

6. Run Fixture's Electrical Wire and Safety cable through every 3rd Link of Chain.

7. Slide Collar and then Canopy over Wire, Cable, and Chain and rest on top of Hub.

8. Attach loose end of Chain to Loop on Canopy Mounting Plate.

9. Secure loose end of Safety Cable to structure ensuring that connection is suitable for a minimum of 90lbs.

10. Make electrical connection following all local codes and procedures.

11. Slide Canopy up Chain and over Mounting Plate. Secure Canopy to Mounting Plate by screwing Collar onto Loop until tight to ceiling.

12. Hang (2) Arms with Wire to Loops with Plugs on bottom of Hub.

Hooks on Arms should be facing in. Connect Plugs from Hub to Plugs on arms.

13. Hang 3 Arms onto remaining Loops on Hub. Hooks on Arms should be facing in.

14. Attach 5 LT Body to Arms. Hooks on Arms should be facing out when attached to Body. Be certain to line up Arms with Wires to Plugs on Body.

15. Connect Plugs from bottom of Arms to Plugs on Body.

16. Hang remaining Arm with Wire from Loop with Plug at bottom of 5 LT Body.

Hook on Arm should be facing in. Connect Plug at top of Arm to Plug on Body.

17. Hang remaining Arms from Loops at bottom of 5 LT Body.

Hooks on Arms should be facing in.

18. Attach 10 LT Body to Arms. Hooks on Arms should be facing out when attached to Body. Be certain to line up Arm with Wire to Plug on Body.

19. Connect Plug from bottom of Arm to Plug on Body.

20. Slide Fiber Drip Candle Covers onto Sockets.

21. Install 15 Medium Base 60Watt Bulbs(not included).

22. Power on and ENJOY!

