

# INSTALLATION INSTRUCTIONS

FOR ITEM 182298 (23" W Tall Pines Inverted Pendant)

**Meyda**  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## Fixture Components

1. CANOPY ASSEMBLY (CROSSBAR, CANOPY, COLLAR & LOOP)
2. QUICK LINK (QTY.- 2)
3. CHAIN (1 FOR HUB AND 4 FOR SHADE)
4. HUB ASSEMBLY
5. SHADE

***Caution:***

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Remove Collar Loop from Canopy Assembly to release Crossbar with Loop and Quick Link.
3. Affix Crossbar to Junction Box ensuring that connection is Suitable for 35 lbs. and that Electrical Supply Wires remain accessible.
4. Attach desired length of Chain to the Quick Link on Hub Assembly.
5. Weave Fixture Lead Wires through every 3rd Link of Chain.
6. Feed Chain through the Collar and Canopy and let Collar and Canopy rest over Hub Assembly.
7. Attach Chain to the Quick Link on Loop of Canopy Assembly.
8. Following all Local Codes and Procedures, make electrical connections from Lead Wires to Supply Wires.
9. Slide Canopy up the Chain to the ceiling and screw Collar onto the Loop until secure.
10. Hang Shade by the Hook to the Hub Assembly.
11. Install 4x 60W E26 A19 bulbs (not included) into sockets.
12. Power on and ENJOY!!!

## **CANOPY ASSEMBLY**

