

INSTALLATION INSTRUCTIONS

FOR ALVA BARTLETT WALL SCONCE 182825

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SPOKED PULLEY ASSEMBLY
2. FLANGE ASSEMBLY
3. SOCKET W/ ATTACHED WIRE
4. STRAIN RELIEF

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.

2. Separate Crossbars from Flange Assembly and Spoked Pulley Assembly by removing Acorn Nuts from face.

3. Mount Flange Assembly Crossbar to J-Box ensuring to pull Lead Wires through.

4. Mount Spoked Pulley Assembly Crossbar to desired position on wall.

5. Slide Spoked Pulley Assembly over studs on Crossbar and secure with Acorn Nuts.

6. Feed wire through Flange Assembly to desired length. Set length by crimping Strain Relief on wire at back of Flange.

7. Connect fixture wires to lead wires from J-Box following all local codes and procedures.

8. Slide Flange Assembly over studs on Crossbar and secure with Acorn Nuts.

9. Run wire over Pulley.

10. Install Medium Base 60 Watt Bulb(not included).

