

INSTALLATION INSTRUCTIONS

FOR CASTILLA 16LT THREE TIER CHANDELIER 183606

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

B1 TOP TIER	8-32 ACORNS (QTY 8)
B2 BOTTOM TIER	CANOPY ASSEMBLY
1/4-20 ACORNS (QTY 6)	CHAIN 72"
STEEL UPRIGHTS (QTY 8)	FIBER DRIP CANDLE COVERS (QTY 16)
1/4-20 BOLTS (QTY 8)	
1/4-20 NUTS (QTY 8)	

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Suspend B2, Bottom Tier, off of the floor on scaffold. Center hub with 1/4-20 bolts should be facing up and accesible. Remove 1/4-20 Acorn nuts from studs and save.
3. Move B1, Top Tier, into position to combine with B2. Connect electrical Molex plugs between B1 and B2.
4. Set B1 onto B2 so that 1/4-20 studs from B2 fit through holes in center bottom hub cap of B1. Reattach Acorn nuts and secure.
5. Remove nuts from studs on hub cap at top of B1 and remove cap.
6. Begin attaching Steel Uprights to fixture. Move uprights into position with pinched ends up. Bottom of uprights will connect to 8/32 studs on inner arms of B2. Once stud is feed through bottom hole of upright, secure using 8/32 Acorn nuts.
7. Top, pinched end of uprights, will attach to top hub of B1. Feed 1/4-20 bolt through uprights and into hub. Secure bolts inside hub, with 1/4-20 nuts.
8. Once all uprights have been secured, reattach hub cap at top of B1.
9. Dissassemble canopy assembly by first removing screw collar from loop. Slide crossbar with attached loop and quick link out of canopy.
10. Secure crossbar to ceiling, ensuring that connection is suitable for minimum of 120lb load and that electrical supply wires are accesible.
11. Attach desired length of chain to quick link on loop at top hub of B1.
12. Slide first screw collar and then canopy over chain and let rest on top of hub at top of B1.
13. Fixture can now be hung. Attach chain to quick link on canopy loop.
14. Run electrical wires through every 3rd link of chain.
14. Make electrical connections to supply power following local codes and procedures.
15. Slide canopy and screw collar up chain. Before attaching canopy, feed safety cable up through chain and, once at top, through outer hole in canopy. Secure safety cable to structure ensuring connection is suitable for minimum 120lb load.
16. Slide canopy up to ceiling and thread screw collar onto loop until tight.
17. Place fiber drip candle covers onto sockets on arms.
18. Install 16-Candelabra 60Watt(bulbs(not included) into sockets on arms.
19. Install 1-Medium 50Watt PAR20 bulb(not included) into downlight socket.