

INSTALLATION INSTRUCTIONS

FOR ITEM 185631 (4.5"W Cilindro Jadestone Wall Sconce)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Fixture Components

1. CROSSBAR W/ STUDS
2. BACKPLATE
3. FRAME
4. SHADE
5. KNULED THUMB SCREW (QTY.- 3)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the Brass Balls at the front to release a Crossbar W/ Studs from Backplate, Save it for later.
3. Using Customer supplied hardware, affix the Crossbar W/ Studs directly to the J-Box, ensuring the connection is suitable for a minimum of 10 lbs. and that electrical supply wires remain accessible.
4. Following all local codes and procedures, make electrical wire connections from supply wire to fixture lead wires.
5. Lift the Frame to the Wall and protrude the Studs through the Backplate.
6. Resecure Frame to the Wall with the Brass Balls from before.
7. Slide Shade over the socket.
8. Secure the Shade using Knurled Thumb Screws.
9. Install 60W E26 BA10 bulb (not included) into the socket.
10. Power On and ENJOY!!!

