

# INSTALLATION INSTRUCTIONS

FOR ITEM 187801

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. 55" L LIGHT BAR W/ LEAD WIRE, SAFETY CABLE, & UNO RINGS(QTY 5)
2. UPROD W/ ATTACHED CANOPY ASSEMBLY
3. SHADE ASSEMBLY (QTY 5)

**Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove 1/4-20 Hex Nuts and 1/4-20 Acorn Nuts from Studs inside top-center cavity of Light Bar.
3. Unravel Fixture Lead Wire and Safety Cable inside top-center cavity of Light Bar.
4. Run Fixture Lead Wire, Copper Ground Wire, & Safety Cable through Uprod and out of top of attached Canopy Assembly.
5. Slide Flange at bottom of Uprod over Studs extending out of top-center cavity of Light Bar.
6. Attach first 1/4-20 Hex Nuts and then 1/4-20 Acorn Nuts to Studs protruding through Flange and secure.
7. Remove 1/4-20 Acorn Nuts from Canopy Assembly to release Mounting Plate.
8. Attach Mounting Plate to ceiling ensuring that connection is suitable for minimum 50lbs.
9. Attach free end of Safety Cable to structure ensuring that connection is suitable for minimum of 50lbs.
10. Make electrical connection from Fixture Lead Wire to Building Line Wire following all local codes and procedures.
11. Once electrical connection has been successfully made, slide canopy over Studs on Mounting Plate.
12. Screw 1/4-20 Acorn Nuts onto Studs extending through Canopy until top of Canopy is flush with ceiling and fixture is secure.
13. Remove Uno Rings from Sockets.
14. Attach Shades by sliding Sockets through Square Spider on top of Shades and secure by screwing Uno Rings onto Sockets until tight.
15. If Shades are not level, adjustments can be made by loosening or tightening Studs that attach Shades to Square Spider. Gentle tweaks may also be necessary.
15. Install 5 Medium Base 60Watt Bulbs(not included) into Sockets.
16. Power on and ENJOY!!!

