

INSTALLATION INSTRUCTIONS

FOR ITEM 189344 Red Rosebud 6 Arm Semi-Flushmount

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Fixture Components

1. CANOPY W/1 ARM & CHANDELIER BODY
2. ARM (QTY 2)
3. ROSEBUD CONE SHADE (QTY 2)
4. HUB CAP AND FINIAL (QTY 2)
5. ROSEBUD SHADE (QTY 6)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Finial from Canopy to release Crossbar w/Threaded Rod. Reserve Finial for later use.
3. Attach Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 20lbs and that Electrical Supply Wires remain accessible.
4. Connect Chandelier Body to Canopy with all Arms.
5. Following All Local Codes and Procedures make electrical connection from Fixture Lead Wires to Supply Wires.
6. Lift Fixture up to ceiling allowing Threaded Rod to pass through center of Canopy. Secure with Finial.
7. Install 2-E12 25 Watt Bulbs(not included) into Hub Sockets.
8. Set Rosebud Cone Shades into Hub Frame and secure with Hub Caps and Finials.
9. Slide Rosebud Shades over Sockets into cup and secure by threading Uno Rings onto Sockets.
10. Install 6-E26 60Watt Bulbs(not included) into Sockets.
11. Power on and ENJOY!!!

