

INSTALLATION INSTRUCTIONS

FOR ITEM ITEM 190598 CILINDRO TEXTRENE FLUSHMOUNT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY/LIGHT CLUSTER ASSEMBLY
2. 48" WIDE SHADE
3. IDALIGHT PANELS (QTY 7)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy to release Universal Crossbar with Studs. Reserve Balls for later use.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware ensuring that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make connection from Canopy/Light Cluster Assembly Lead Wires to Supply Wires.
5. Lift Canopy up the ceiling allowing Crossbar Studs to pass through. Secure with reserved Brass Balls.
6. Using Shade Mounting Diagram, prepare ceiling at Shade Connection Points.
7. Using Customer Supplied Hardware, affix Shade to ceiling ensuring that connection is suitable to hold a minimum of 30lbs.
8. Install 8 Medium Base 8Watt LED Bulbs(not included) into Sockets.
9. Lift Idalight Panels up through bottom of Shade and allow them to rest on Steel Slats of Shade Frame. Ensure that frosted side of Idalight Panel is facing out.
10. Power on and ENJOY!!!

