

INSTALLATION INSTRUCTIONS

FOR ITEM 190767 Fleur-de-lis Inverted Pendant

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 240" CHAIN
3. HUB W/ 5"W SHADE, WIRE, AND 27" ARM
4. 27" ARM W/ CHAIN LINK ATTACHED AT EITHER END (QTY 7)
5. 45"W SHADE RING
6. 40"W FLEUR-DE-LIS SHADE
7. CROSS BAR W/ 8 LIGHT CLUSTER

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screw Collar for Canopy Assembly to release Heavy Duty Crossbar w/ attached Nipple, Ring, and Quick Link.
3. Mount Crossbar to structure ensuring that connection is suitable for minimum 70lbs and that Electrical Line Wires remain accessible.
4. Unravel Fixture Lead Wire from top of Hub.
5. Attach desired length of Chain to Quick Link at top of Hub.
6. Run Fixture Lead Wire up Chain. It is recommended to weave Wire through every 3rd Link of Chain.
7. Slide first Screw Collar and then Canopy over Chain and Wire and let rest on top of Hub.
8. Attach loose end of Chain to Quick Link on Crossbar.
9. Feed Fixture Lead Wire through Crossbar Loop and make electrical connection to Structure Line Wires following all Local Codes and Procedures.
10. Slide Canopy and Screw Collar up Chain and thread Screw Collar onto Nipple until top of Canopy is flush with ceiling.
11. Hang 27" Arms from Hooks on Hub.
12. Set 40"W Fleur-de-lis Shade into 45"W Shade Ring.
13. Hang Shade with Shade Ring from loose ends of 27" Arms ensuring to line up either Stud on inside of Ring with Electrical Plug from Arm.
14. Remove Hex Nuts from Studs on Ring and set Crossbar with Light Cluster onto Studs ensuring that Electrical Receptacle on Crossbar lines up with Electrical Plug from Arm. Insert Plug into Receptacle. Thread Hex Nuts back onto Studs.
15. Unscrew Finial at bottom of Hub Shade and remove Shade. Be careful not to let Shade fall when removing finial.
16. Install 2 Candelabra 15Watt Bulbs(not included) into Sockets inside Hub.
17. Replace Hub Shade and screw Finial onto Threaded Rod until Shade is secure.
18. Install 8 Medium 60Watt Bulbs(not included) into Light Cluster Sockets.
19. Power on and ENJOY!!

