

INSTALLATION INSTRUCTIONS

FOR ITEM 201776 Pine Goblit 3 Light Vanity

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. WALL SCONCE HARDWARE
2. HAND PAINTED GLASS SHADE (QTY 3)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Nuts from face of Wall Sconce Hardware to release Crossbar. Reserve Nuts for later use.
3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 5lbs and that Electrical Supply Wires remain accessible.
4. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
5. Slide Wall Sconce Hardware onto Crossbar Studs and secure with reserved Nuts.
6. Remove Uno Rings from Sockets.
7. Slide Shades over Sockets and secure with Uno Rings.
8. Install 3-E26 60Watt Bulbs(not included) into Sockets.
9. Power on and ENJOY!!!

