

INSTALLATION INSTRUCTIONS

FOR ITEM 205555 MAPLEWOOD INVERTED PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. DOWN ROD
3. PENDANT BODY
4. GLASS PANEL (QTY 4)
5. SILICONE

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.

2. Apply dabs of Silicone around edges of openings in bottom of Pendant Body Frame. Push Glass Panels, smooth side down, into Silicone and allow to cure per instructions on tube. Any excess Silicone can be removed with a razor blade once dried.

3. Remove Brass Balls from Canopy Assembly to release Mounting Plate with Saddle. Reserve Balls for later use.

4. Affix Fixture Mounting Plate with Saddle to structure ensuring that connection is suitable for minimum of 65lbs and that Electrical Supply Wires remain accessible.

5. Unravel Fixture Lead Wires and Safety Cable from top of Pendant Body and feed through Down Rod.

6. Attach Down Rod Flange to top of Pendant Body and secure with Hex and Acorn Nuts.

7. Slide Canopy Cover Plate and Canopy over Down Rod and allow to rest on top of Pendant Body.

8. Slide Steel-Half Ball over Down Rod. Insert Spring Pin through channel at top of Down Rod. Hold Steel-Half Ball to allow Spring Pin to seat inside. Bend Pegs from Half Ball over Spring Pin to hold in place.

9. Lift Fixture up to Mounting Plate and seat Steel-Half Ball in Mounting Plate Saddle.

10. Secure Fixture Safety Cable to structure ensuring that connection is suitable for minimum 65lbs.

11. Make electrical connection from Fixture Lead Wires to Structure Supply Wires following all Local Codes and Procedures.

12. Slide Canopy and Cover Plate up Rod and secure to Mounting Plate Studs using reserved Brass Balls.

13. Install 4 Medium Base 60Watt Bulbs(not included) into horizontal Sockets and 4 Medium Base 50Watt MR16 Bulbs(not included) into Down Light Sockets.

14. Power on and ENJOY!!!

