

INSTALLATION INSTRUCTIONS

For Item 20927 Scottsdale Mission Pendant

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 84" CHAIN
- 3 SHADE FRAME
4. LIGHT CLUSTER W/LEAD WIRE
5. GLASS PANEL (QTY 4)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Collar from Canopy Assembly to release Crossbar with Loop and Quick Link.
3. Affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 35lbs and that Electrical Supply Wires remain accessible.
4. Lie Shade Frame on its side to install Glass Panels. Glass **Panels can be installed with the textured side facing in or out based on personal preference.**
5. Hold Glass Panel at a slight angle and insert into Shade Frame. Once Panel is fully inside Frame, straighten and slide it into top channel then lower into bottom channel.
6. Gently roll Shade Frame and install next Panel following previous instruction.
7. Follow the previous instruction to install remaining Panels.
8. Feed Lead Wire from Light Cluster through Stem inside Shade Frame and out of Shade Loop.
9. Screw Threaded Nipple at top of Light Cluster into Coupling on Shade Frame Stem. Tighten Cluster until secure and Sockets are facing corners of Shade Frame.
10. Carefully stand Shade up and attach desired length of Chain to Quick Link on Shade Loop.
11. Weave Lead Wires through every 5th Link of Chain.
12. Slide Collar and Canopy over Chain and Lead Wires and allow them to rest on top of Shade.
13. Hang Shade by connecting loose end of Chain to Quick Link on Crossbar Loop.
14. Feed Lead Wires through Crossbar Loop and, following all local codes and procedures, make connection from Lead Wires to Supply Wires.
15. Slide Canopy up to ceiling and secure by screwing Collar onto Crossbar Loop.
16. Install 4-E26 40Watt Bulbs(not included) into Sockets.
17. Power on and ENJOY!!!

