

INSTALLATION INSTRUCTIONS

FOR ITEM 211859

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 72" CHAIN
3. PENDANT BODY
4. GLASS PANEL (QTY 8, A1-A8)
5. CANDLE COVER (QTY 8)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Collar from Canopy Assembly to release Mounting Plate with attached Brass Loop and Quick Link. Reserve Collar for later use.
3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 150lbs. and that Electrical Supply Wires remain accessible.
4. Using an Allen Key and Nut Driver, loosen Acorn Nuts at interior-base of Pendant Body to allow Arrow Plates to slide freely.
5. Remove Acorn Nuts from interior-top of Pendant Body and remove Steel Corner Straps. Reserve all parts for later use.
6. Holding at an angle left to right, lower Glass Panel A1 into Pendant Body at Side A1. Allow Glass Panel to rest on Pendant Base Ridge between Arrow Plate and Frame. Use Painter's Tape to temporarily hold Panel in place.
7. Holding at an angle left to right, lower Glass Panel A2 into Pendant Body at Side A2. Allow Glass Panel to rest on Pendant Base Ridge between Arrow Plate and Frame. Use Painter's Tape to temporarily hold Panel in place.
8. Once 2 adjacent Panels have been inserted, lower Steel Corner Strap into gap between Panels. Insert bottom of Strap between Arrow Plate and Glass and allow Stud to top of Frame to pass through Slot in top of Strap. Secure at top with reserved Acorn Nut and at bottom by tightening Acorn Nut.
9. Repeat Steps 6-8 until remainder of Glass has been installed.
10. Attach desired length of Chain to Quick Link at top of Pendant Body.
11. Unravel Safety Cable and Fixture Lead Wires and weave them through every 5th Link of Chain.
12. Slide Screw Collar and Canopy over Chain, Cable, and Wires and allow them to rest at top of Pendant Body.
13. Lift Fixture up to ceiling and hang by connecting loose end of Chain to Quick Link on Brass Loop.
14. Slide Canopy and Screw Collar up Chain and feed Safety Cable through satellite hole in Canopy. Secure Cable to structure ensuring that connection is suitable to hold a minimum of 150lbs.
15. Feed Fixture Lead Wires through Channel in Brass Loop and, Following all Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
16. Lift Canopy up to ceiling and secure by Threading Screw Collar onto Brass Loop until tight.
17. Slide Candle Covers over Sockets.
18. Install 8 Candelabra Base 60Watt Bulbs(not included) into Sockets.
19. Power on and ENJOY!!!

PG 1 of 2

INSTALLATION INSTRUCTIONS

FOR ITEM 211859

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*
Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Caution:
Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.
Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.

