

INSTALLATION INSTRUCTIONS

FOR ITEM 214021 CILINDRO STRUCTURE PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. CONDUIT W/ THREADED ROD
3. PENDANT BODY

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy Assembly to release Crossbar. Reserve Brass Balls for later use.
3. Affix Crossbar to ceiling ensuring that connection is suitable to hold a minimum of 60lbs and that electrical supply wires remain accessible.
4. Unravel Fixture Lead Wires and Safety Cable from top of Pendant Body and feed them through Conduit w/ Threaded Rod.

*****IF SHORTER OVERALL FIXTURE HEIGHT IS DESIRED, CUT EQUAL LENGTH FROM CONDUIT AND THREADED ROD PRIOR TO RUNNING WIRES. THREADED ROD SHOULD EXTEND .5" BEYOND OUTER CONDUIT AFTER CUTTING.*****

5. Screw Threaded Rod into Coupling at top of Pendant Body.
6. Feed Fixture Lead Wires and Safety Cable through Canopy.
7. Screw Canopy onto exposed Threaded Rod at top of Conduit.
8. Run Aircraft Cables from Canopy to Cable Grippers on Pendant Body. Loosen Nut on Gripper and feed Cable through until taut. Tighten Nuts. Excess Cable can be cut once set.
9. Install 10 Medium Base 40Watt Bulbs(not included) into Sockets.
10. Secure Safety Cable to structure ensuring that connection is suitable to hold a minimum of 60lbs.
11. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
12. Lift assembled Fixture up to ceiling allowing Crossbar Studs to protrude through Canopy. Secure with reserved Brass Balls.
13. Remove protective shrink wrap from Pendant Body.
14. Power on and ENJOY!!!

