

INSTALLATION INSTRUCTIONS

FOR ITEM 214186 WOOD BEAM 6 LIGHT PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. STEM
3. PENDANT BODY

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy Assembly to release Mounting Saddle. Reserve Balls for later use.
3. Using Customer Supplied Hardware, affix Mounting Saddle to ceiling ensuring that connection is suitable to hold minimum of 40lbs and that Electrical Supply Wires remain accessible.

If it desired to have a lesser overall drop from the ceiling, cut desired length from top of Stem. ie. If the Fixture currently has a drop of 48" from ceiling and the desired drop is 36", 12" should be cut from the top of the Stem. Once Stem has been cut, drill 1/4" hole on either side of the Stem, 1/2" from the cut end. This will create the new Spring Pin through holes.

4. Feed Lead Wires through Stem and attach Stem Plate to Pendant Body Hub.
5. Slide Canopy Cover Plate, Canopy, and Steel Half Ball over Lead Wires and Stem and allow them to rest on Hub.
6. Feed Spring Pin through holes at top of Stem.
7. Slide Steel Half Ball up Stem allowing Spring Pin to seat into Half Ball ditch. Temporarily secure it in place by wrapping Weld Pins over Spring Pin.
8. Lift Fixture up to ceiling and seat Half Ball into Mounting Saddle.
9. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
10. Slide Canopy and Cover Plate up Stem allowing Mounting Saddle Studs to pass through. Secure with reserved Brass Balls.
11. Install 6 Medium Base 6.5Watt LED Bulbs(not included) into Sockets.
12. Power on and ENJOY!!!

