

INSTALLATION INSTRUCTIONS

FOR ITEM 214875 FARMINGTON 8 LT CHANDELIER

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- | | |
|--------------------|--|
| 1. CANOPY ASSEMBLY | 5. ACRYLIC CYLINDER (QTY 8) |
| 2. CANOPY STEM | 6. CYLINDER ATTACHMENT HARDWARE |
| 3. FIXTURE STEM | 7. ANTI-SWAY CHAIN (QTY 4) |
| 4. FIXTURE BODY | 8. ANTI-SWAY WALL MOUNT HARDWARE (QTY 4) |

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- Carefully unpack all components and make certain that everything is accounted for.
- Remove 1/4-20 Hex and Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve nuts for later use.
- Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 130lbs. and that electrical supply wires remain accessible.
- Unravel Fixture Lead Wires and Safety Cable from top-center of Fixture Body and feed them through tapered end of Fixture Stem.
Fixture Stem has 1 tapered end and opposite end with (2) 3/8" holes.
- Remove 3/8-16 Bolts and Nuts from Fixture Body Stem Receptacle and insert tapered end of Fixture Stem. Secure with Bolts and Nuts.
- Remove 3/8-16 Bolts and Nuts from top of Fixture Stem and reserve.
- Feed Fixture Lead Wires and Safety Cable through tapered end of Canopy Stem.
Canopy Stem has 1 tapered end and opposite end with (1) 3/8" hole.
- ***IF SHORTER OVERALL FIXTURE HEIGHT IS DESIRED, BEFORE FEEDING WIRES THROUGH, CUT LENGTH FROM CANOPY STEM ON 3/8" HOLE SIDE. ONCE CUT, DRILL NEW 3/8" HOLE 3/4" FROM END OF STEM.*****
- Insert tapered end of Canopy Stem into top of Fixture Stem and secure with reserved 3/8-16 Bolts and Nuts.
- Feed Fixture Lead Wires and Safety Cable through central holes in Canopy.
- Remove 3/8-16 Bolt and Nuts from Canopy Dog Ears and attach to Canopy Stem with 3/8-16 Bolt and Nuts.
- Secure Safety Cable to structure ensuring that connection is suitable to hold 130lbs.
- Following all Local Codes and Procedures, make electrical Connection from Fixture Lead Wires to Supply Wires.
- Lift Fixture up to ceiling allowing Mounting Plate Studs to protrude through Canopy. Secure with reserved 1/4-20 Hex and Acorn Nuts.
- Set Acrylic Cylinders into Fixture Body Cups. Be sure to align holes in bottom of Cylinders with Studs. Secure Cylinders with provided Plastic Washers and Hex Nuts onto Studs.
- Install 8 Medium Base 40Watt Bulbs(not included) into Acrylic Cylinder Sockets. Install 8 Medium Base 40Watt Par20 Bulbs(not included) into Down Light Sockets.
- Install Anti-Sway Wall Mount Hardware in desired locations.
- Attach Anti-Sway Chains to loops on Fixture Body using Quick Links and run Chains to Wall Mount Hardware. Connect with Quick Links.
- Power on and ENJOY!!!

INSTALLATION INSTRUCTIONS

FOR ITEM 214875 FARMINGTON 8 LT CHANDELIER

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- | | |
|--------------------|--|
| 1. CANOPY ASSEMBLY | 5. ACRYLIC CYLINDER (QTY 8) |
| 2. CANOPY STEM | 6. CYLINDER ATTACHMENT HARDWARE |
| 3. FIXTURE STEM | 7. ANTI-SWAY CHAIN (QTY 4) |
| 4. FIXTURE BODY | 8. ANTI-SWAY WALL MOUNT HARDWARE (QTY 4) |

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.
Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.

