

INSTALLATION INSTRUCTIONS

FOR ITEM 215322 KITZI BOX PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. CHAIN
3. PENDANT BODY
4. GLASS PANEL (QTY 4)
5. CORNER BRACKET (QTY 4)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts for later use.
3. Attach Mounting Plate to ceiling ensuring that the connection is suitable to hold a minimum of 85lbs and that electrical supply wires remain accessible.
4. Attach desired length of Chain to Quick Link at top of Pendant Body.
5. Weave Fixture Lead Wires and Safety Cable through every 3rd Link of Chain.
6. Attach loose end of Chain to Quick Link on Canopy.
7. Feed Lead Wires and Safety Cable through Canopy.
8. Secure Safety Cable to structure ensuring that connection is suitable to hold a minimum of 85lbs.
9. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Structure Supply Wires.
10. Lift Fixture up to ceiling allowing Mounting Plate Studs to protrude through Canopy. Secure with reserved Nuts.
11. Lift Glass Panel at a slight left to right angle into Inner Box of Pendant Body. Once Panel has cleared Frame, straighten and slide into top channel and then let rest in bottom channel.
12. Once panels have been installed, secure with Corner Brackets.
13. Install 8 Medium Base 60Watt Bulbs(not included) into Sockets.
14. Power on and ENJOY!!!

