

INSTALLATION INSTRUCTIONS

FOR ITEM 216718 CILINDRO ASHCROFT 2 LT WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. WALL SCONCE HARDWARE
2. CRACKLE GLASS SHADE (QTY 2)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screws from Wall Sconce Hardware Backplate to release Crossbar. Reserve Screws for later use.
3. Using Customer Supplied Hardware affix Crossbar to Junction Box ensuring that connection is suitable to hold 5lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Slide Sconce Backplate over Crossbar ensuring to align holes and secure with reserved Screws.
6. Install 2 Candelabra Base 40Watt Bulbs(not included) into Sockets.
7. Set Glass Shades, threaded side down, into Cups and twist Clockwise only far enough for threads to engage. **DO NOT OVER TIGHTEN.** Care should be taken to ensure threads are not crossed. Cease twisting if any resistance is felt and begin this step again.
8. Power on and ENJOY!!!

