

INSTALLATION INSTRUCTIONS

FOR ITEM 216719 CILINDRO ASHCROFT 6 LT WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. WALL SCONCE HARDWARE
2. SCONCE UPPER ROUND TUBE-12"
3. SCONCE LOWER ROUND TUBE-8"
4. CRACKLE GLASS SHADE (QTY 6)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screws from Wall Sconce Hardware Backplates to release Crossbars. Reserve Screws for later use.
3. Using Customer Supplied Hardware affix Crossbars to Junction Boxes ensuring that connections are suitable to hold 15lbs and that Electrical Supply Wires remain accessible. Fixture Lead Wires are accessed in the top Hardware Backplate.
5. Following all Local Codes and Procedures, make electrical connection from Lead Wires to Supply Wires.
6. Screw Sconce Upper Tube(12") into top of Sconce and Lower Tube(8") into bottom of Sconce.
7. Slide Sconce Backplates over Crossbars ensuring to align holes and secure with reserved Screws.
8. Install 6 Candelabra Base 40Watt Bulbs(not included) into Sockets.
9. Set Glass Shades, threaded side down, into Cups and twist Clockwise only far enough for threads to engage. DO NOT OVER TIGHTEN. Care should be taken to ensure threads are not crossed. Cease twisting if any resistance is felt and begin this step again.
10. Power on and ENJOY!!!

