

# INSTALLATION INSTRUCTIONS

FOR ITEM 218698 CARTIER 9 LIGHT CHANDELIER

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 72" STEM (QTY 3)
3. CHANDELIER BODY
4. SHADE (QTY 9)

### Caution:

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Acorn Nuts for later use.
3. Using Mounting Plate as template, install blocking in ceiling. Ensure blocking is sufficient to hold a minimum of 75lbs.
4. Using Customer Supplied Hardware, affix Mounting Plate to blocking ensuring that connection is suitable to hold a minimum of 75lbs and that Electrical Supply Wires remain accessible.
5. Remove Acorn Nuts and Half Balls from top of Chandelier Body to release Cover Plate. Reserve Nuts and Half Balls for later use.
6. Attach 72" Stems to Cover Plate using Spider Washers and Hex Nuts.
7. Feed Fixture Lead Wires up through Cover Plate and Stem.
8. Set Cover Plate on top of Chandelier Body and secure with reserved Acorn Nuts and Half Balls.
9. Feed Fixture Lead Wires through Canopy and set Canopy on top Stems. Secure Canopy to Stems with Spider Washers and Hex Nuts.
10. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
11. Lift Chandelier up to ceiling allowing Mounting Plate Studs to pass through Canopy. Secure Chandelier with reserved Acorn Nuts.
12. Slide Shades over Sockets and secure with Plastic Spacer and Uno Ring.
13. Install 9 Medium Base 60Watt Bulbs(not included) into Sockets.
14. Power on and ENJOY!!!

