

INSTALLATION INSTRUCTIONS

FOR ITEM 219695 ALVA CILINDRO PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. LEAD WIRE STEM (QTY 2)
3. SAFETY CABLE STEM (QTY 2)
4. PENDANT BODY

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Hex and Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts for later use.
3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 150lbs and that Electrical Supply Wires remain accessible.

*****If desired, a lesser overall drop from the ceiling can be achieved. Remove Wires and Cables from Stems, separate and cut an equal length from Threaded Rod and Outer Conduit then reassemble.*****

4. Remove Hex Nut and Spider Washer from Lead Wire Stem, end opposite of Connection Plate, and feed Wires and exposed Threaded Rod through Canopy. Secure Stem to Canopy with Spider Washer and Hex Nut. Ensure that concave side of Connection Plate faces to the center. Follow this procedure for other Wired Stem. Wired Stems should be installed through opposing holes in Canopy.
5. Remove Hex Nut and Spider Washer from Safety Cable Stem, end opposite of Connection Plate, and feed Safety Cable and exposed Threaded Rod through Canopy. Secure Stem to Canopy with Spider Washer and Hex Nut. Ensure that concave side of Connection Plate faces to the center. Follow this procedure for other Stem. Stems with Cables should be installed through opposing holes in Canopy.
6. Attach loose ends of Safety Cables to secure location ensuring that connection is suitable to hold a minimum of 150lbs.
7. Following all Local Codes and Procedures, make Electrical Connection from Fixture Lead Wires to Supply Wires.
8. Lift Canopy up to Mounting Plate allowing Studs to pass through. Secure using reserved Hex and Acorn Nuts.
9. Remove Acorn Nuts from Stem connection points on top of Pendant Body. Reserve Acorn Nuts for later use.
10. Make electrical connections from Plugs on Wired Stems to Receptacles in Pendant Body.
11. Lift Pendant Body to allow Connection Plates to engage Studs on Pendant Body. Secure with reserved Acorn Nuts.
12. Install 16 Medium Base 40Watt Bulbs(not included) into Sockets.
13. Power on and ENJOY!!!

