

# INSTALLATION INSTRUCTIONS

FOR ITEM 220082 ALVA CASCADING PENDANT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. MOUNTING PLATE
2. CHANDELIER BODY

### **Caution:**

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Hex and Acorn Nuts from Mounting Plate Studs and reserve.
3. Using Customer Supplied Hardware, affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 100lbs. Placement of Mounting Plate should be such that 1 set of Mounting Plate Studs are ~40° from J-Box. Ensure that Electrical Supply Wires extend through Plate.
4. Carefully disassemble wooden frame on 1 side of Chandelier Body to use for extraction.
5. Remove bolts holding Chandelier Body to steel frame and extract. Keep in mind that once bolts are removed Chandelier will need to be otherwise supported. Fixture is shipped with a support chain attached and can be temporarily held by said chain once removed from shipping crate. Chain needs to be removed before final installation.
6. Remove Wire Access Panel from Chandelier Canopy and direct Lead Wire out through opening.
7. Lift Chandelier up to ceiling allowing Mounting Plate Studs to pass through Canopy and secure with reserved Hex and Acorn Nuts. Be sure to align Wire Access opening with J-Box as closely as possible.
8. Following all Local Codes and Procedures, make electrical connection from Lead Wires to Supply Wires, push Wires into Canopy, and close Access Panel.
9. Install 40 Medium Base 5Watt LED Bulbs(not included) into Sockets.
10. Power on and ENJOY!!!

