

# INSTALLATION INSTRUCTIONS

FOR ITEM 220216 GREENBRIAR OAK INVERTED PENDANT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 108" CHAIN
3. HUB w/ STEM & LIGHT CLUSTER
4. ARM (QTY 4)
5. STAINED GLASS SHADE
6. LEAF AND ACORN CROWN
7. THREADED ROD w/ FINIAL

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Collar from Canopy Assembly to release Crossbar with attached Loop. Reserve Collar for later use.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware ensuring that connection is suitable to hold a minimum of 40lbs and that Electrical Supply Wires remain accessible.
4. Attach desired length of Chain to Quick Link at top of Hub.
5. Weave Fixture Lead Wires through every 5th Link of Chain.
6. Slide Screw Collar and Canopy over Chain and Wires and allow them to rest on top of Hub.
7. Hang Hub w/ Light Cluster by connecting loose end of Chain to Quick Link on Crossbar Loop.
8. Feed Fixture Lead Wires through Channel in Crossbar Loop.
9. Following all Local Codes and Procedures, make Electrical Connection from Fixture Lead Wires to Supply Wires.
10. Slide Canopy up Chain to ceiling and secure by screwing Collar onto Crossbar Loop.
11. Hang Arms from vacant Loops on Hub. Arms should curve out from center of the Fixture.
12. Set Leaf and Acorn Crown on top of Stained Glass Shade.
13. Hang Stained Glass Shade by attaching free ends of Arms to Loops on Shade.
14. Insert Threaded Rod up through bottom of Stained Glass Shade and screw into Coupling at bottom of Light Cluster.
15. Install 3 Medium Base 60Watt Bulbs(not included) into Sockets.
16. Power on and ENJOY!!!

