INSTALLATION INSTRUCTIONS

FOR ITEM 220740 GRAND TERRACE 14 LT OBLONG CHANDELIER



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY

2. STEM A1

3. STEM A2 w/ SCREWS

4. STEM A3 w/ SCREWS

5. CHANDELIER BODY

6. SAFETY CABLE (QTY 2)

7 LEAD WIRE (ALL BLACK)

8. LEAD WIRE (BLACK & WHITE)

9. COPPER GOUND WIRE

10. GLASS CYLINDERS (QTY 14)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Acorn Nuts for later use.
- 3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires remain accessible.
- 4. Remove Hex Nuts and Spider Washers from Canopy interior and set Canopy on top of Stem A1 allowing Threaded Nipples to protrude through. Secure with Spider Washers and Hex Nuts.
- 5. Remove Screws from top of Stem A2. Connect Stem A1 to Stem A2 by threading Screws through Plate at bottom of A1 into Bar at top of A2.
- 6. Remove Screws from top of Stem A3. Connect Stem A2 to Stem A3 by threading Screws through Plate at bottom of A2 into Bar at top of A3.
- 7. Feed single Safety Cable and all Black Lead Wire through 1 side of Stem Assembly. Electrical Molex Connector and looped end of Safety Cable should remain at bottom of Assembly.
- 8. Feed other Safety Cable, Black and White Lead Wires, and Copper Ground through opposite side of Stem Assembly. Electrical Molex Connector and looped end of Safety Cable should remain at bottom of Assembly.
- 9. Ensuring to match Lead Wire colors, make connections from Lead Wires at top of Chandelier Body to Wires previously run through Stem Assembly. Make Copper Ground Wire connection as well.
- 10. Connect Quick Links at top of Chandelier Body to looped ends of Safety Cables previously run through Stem Assembly.
- 11. Remove Screws from top of Chandelier Body and prepare to attach Stem Assembly. All excess Cable and Wire should be fed into Stem Assembly ensuring to feed Safety Cables and Quick Links into Stems first and then Lead Wires and Molex connections. Once Cables and Wires are inside Stems, set Stem Assembly onto Chandelier Body and secure with Screws.
- 12. Secure Safety Cables to Structure ensuring that connections are suitable to hold a minimum of 100lbs.
- 13. Following all Local Codes and Procedures, make electrical connections from Fixture Lead Wires to Supply Wires. All Black Lead Wires power LED downlights. Black and White Leads power Medium Base Lamps.
- 14. Lift assembled Fixture up to ceiling allowing Mounting Plate Studs to protrude through Canopy. Secure using reserved Acorn Nuts.
- 15. Set Glass Cylinders into cups on Chandelier Body.
- 16. Install 14 Medium Base 60 Watt T10 Bulbs(not included) into Sockets.
- 17. Power on and ENJOY!!!

INSTALLATION INSTRUCTIONS

FOR ITEM 220740 GRAND TERRACE 14 LT OBLONG CHANDELIER



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. STEM A1
- 3. STEM A2 w/ SCREWS
- 4. STEM A3 w/ SCREWS
- 5. CHANDELIER BODY

- 6. SAFETY CABLE (QTY 2)
- 7 LEAD WIRE (ALL BLACK)
- 8. LEAD WIRE (BLACK & WHITE)
- 9. COPPER GOUND WIRE
- 10. GLASS CYLINDERS (QTY 14)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.

Be sure power is off at the main breaker box prior to installation.

Read all instructions in their entirety before beginning installation.

