

INSTALLATION INSTRUCTIONS

FOR ITEM 220846 GREENBRIAR OAK PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 12" CHAIN
3. HUB, LEAD WIRES, LIGHT CLUSTER
4. ARM (QTY 4)
5. STAINED GLASS SHADE
6. LEAF AND ACORN CROWN
7. CLEAR ACRYLIC SHADE COVER
8. THREADED ROD W/ FINIAL

Caution:

**Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Collar from Canopy Assembly to release Crossbar with attached Loop and Quick Link.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware ensuring that connection is suitable to hold a minimum of 30lbs and that Electrical Supply Wires remain accessible.
4. Unravel Fixture Lead Wires from top of Hub and connect desired length of Chain to Quick Link.
5. Weave Lead Wires through every 3rd Link of Chain.
6. Slide Screw Collar and Canopy over Chain and Lead Wires and allow them to rest on top of Hub.
7. Hang Hub by connecting loose end of Chain to Quick Link on Crossbar Loop.
8. Feed Fixture Lead Wires through Channel in Crossbar Loop.
9. Following all Local Codes and Procedures, make electrical connection from Lead Wires to Supply Wires.
10. Slide Canopy up Chain to ceiling and secure by screwing Collar onto Crossbar Loop.
11. Set Leaf and Acorn Crown on top of Stained Glass Shade.
12. Lift Shade up to hanging Fixture allowing Light Cluster to enter center of Shade and connect Shade to Hub with Arms.
13. Slide bare end of Threaded Rod up through bottom hole in Stained Glass Shade and screw into Coupler at Bottom of Light Cluster until Finial Cap meets bottom of Shade.
14. Install 3 GU24 Base 12Watt LED Bulbs(not included) into Sockets.
15. Lift Leaf and Acorn slightly to allow clearance to slide Clear Acrylic Shade Covers in between Arms. Once both Covers have been placed over top Shade opening, lower Crown back onto top of Shade.
16. Power on and ENJOY!!!

