## INSTALLATION INSTRUCTIONS

FOR ITEM 222159 KRONICK FLUSHMOUNT



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

- 1. FIXTURE HARDWARE
- 2. 51.5"H IDALIGHT PANEL (QTY 4)
- 3. 39"H IDALIGHT PANEL (QTY 6)
- 4. 30"H IDALIGHT PANEL (QTY 6)
- 5. 21.5"H IDALIGHT PANEL (QTY 6)

## Caution:

## Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Hex and Acorn Nuts from Fixture Hardware to release Mounting Plate. Reserve Nuts for later use.
- 3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 130lbs and that of Electrical Supply Wires.
- 4. Following all Local Codes and Procedures, make electrical connection from Lead Wires to Supply Wires.
- 5. Lift Fixture Hardware up to ceiling allowing Mounting Plate Studs to pass through. Secure with reserved Hex and Acorn Nuts.
- 6. Install 12 GU10 Base 7Watt MR16 LED Bulbs(not included) into Sockets.
- 7. Install Idalight Panels beginning with 51.5"H Panels at the center of the Fixture Hardware. Holding Panel with Concave side facing in, lift Panel up allowing Panel Tabs to pass through Slots. Twist Panel to the right until Shade Tabs engage Slots. Center of Installed Panels should be aligned with center of Sockets.
- 8. Install remainder of Panels following the previous instruction. Start with next longest Panels closest to center and work outward, ending with shortest Panels furthest from center. When beginning a new row, ensure that the center of the first Panel installed overlaps a gap between Panels from the previous row.

  9. Power on and ENJOY!!!
- Fixture Hardware should be cleaned with a Stainless Steel Cleaner & Polish such as Weiman Brand. Idalight Panels can be cleaned with Plastic Cleaner such as Sprayway Brand SW-848.

