

FOR ITEM 226135 BECKAM WALL SCONCE



Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

1. WALL SCONCE HARDWARE
2. 12" CRYSTAL BAGUETTE (QTY 18)
3. 16" CRYSTAL BAGUETTE (QTY 12)

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Brass Balls from Wall Sconce Hardware to release Crossbar with Studs.
Reserve Brass Balls for later use.
3. USING CUSTOMER SUPPLIED FASTENERS, affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 15lbs and that electrical supply wires remain accessible.
4. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
5. Slide Wall Sconce Hardware onto Crossbar Studs and secure with Reserved Brass Balls.
6. Install 2 Candelabra Base 60Watt Bulbs(not included) into Sockets.
7. Hang 16" Baguettes by slightly opening Wire Hangers and feeding Wire through Slots in Lower Beam.
8. Hang 12" Baguettes by slightly opening Wire Hangers and feeding Wire through Slots in Top Beam.
9. Power on and ENJOY!!!

