

INSTALLATION INSTRUCTIONS

FOR ITEM 226828 CILINDRO TEXTRENE PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. DOWN ROD- CONDUIT + THREADED ROD
3. SHADE CROSSBAR W/ LIGHT CLUSTER AND LEAD WIRES
4. 48"W FABRIC SHADE
5. THREADED ROD W/ FINIAL
6. IDALIGHT DIFFUSER
7. CHECK RING, SPIDER WASHER, 1/4 IP HEX NUT,
6-32 BUTTON HEAD CAP SCREW(QTY 4), 6-32 HEX NUT(QTY 4)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy Assembly to release Crossbar with Studs. Reserve Balls for later use.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware ensuring that connection is suitable to hold a minimum of 35lbs. and that Electrical Supply Wires remain accessible.
IF LESSER OVERALL DROP FROM THE CEILING IS DESIRED, CUT AN EQUAL LENGTH FROM BOTH THREADED DOWN ROD AND CONDUIT PRIOR TO FEEDING WIRE THROUGH. ENSURE THAT THREADED DOWN ROD REMAINS 1" LONGER THAN CONDUIT AFTER CUTS.
4. Unravel Lead Wires from top of Shade Crossbar and feed them through the Threaded Down Rod. Screw Threaded Down Rod into Coupling at center of Shade Crossbar.
5. Slide Conduit over Lead Wires and Threaded Down Rod.
6. Feed Lead Wires through Check Ring and then through Canopy and set on top of Down Rod Assembly. Recessed side of Check Ring should sit onto Down Rod Conduit.
7. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
8. Lift Assembly up to ceiling, allowing Crossbar Studs to pass through Canopy. Secure with reserved Brass Balls.
9. Lift Fabric Shade up to Shade Crossbar ensuring to align Shade tabs with holes at ends of Crossbar. Secure Shade to Crossbar with 6-32 Button Head Screws and 6-32 Hex Nuts.
10. Install 8 Medium Base 60Watt Bulbs(not included) into Sockets.
11. Lift Diffuser up and into bottom of Shade below Pegs. Secure by feeding Threaded Rod with Finial through center hole and screwing into Coupling at bottom of Light Cluster.
12. Power on and ENJOY!!!

