

INSTALLATION INSTRUCTIONS

FOR ITEM 226829 CILINDRO TEXTRENE PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. DOWN ROD- CONDUIT + THREADED ROD
3. 36" FABRIC SHADE
4. LIGHT CLUSTER W/ STEM & LEAD WIRE
5. THREADED ROD W/ FINIAL
6. IDALIGHT DIFFUSER
7. CHECK RING, SPIDER WASHER, 1/4 IP HEX NUT, KNURLED NUT, COUPLING

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Brass Balls from Canopy Assembly to release Crossbar with Studs. Reserve Balls for later use.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware ensuring that connection is suitable to hold a minimum of 20lbs. and that Electrical Supply Wires remain accessible.
4. Unravel Lead Wire from top of Light Cluster and from inside of Shade, feed Lead Wire up through central hole in Shade Spider.
5. Slide Knurled Nut and Coupling over Lead Wire. Connect Cluster to Shade Spider by lifting Cluster up until exposed Threaded Nipple protrudes through central hole. Secure by screwing Knurled Nut and Coupling onto Nipple until tight.
- ***IF LESSER OVERALL DROP FROM THE CEILING IS DESIRED, CUT AN EQUAL LENGTH FROM BOTH THREADED DOWN ROD AND CONDUIT PRIOR TO FEEDING WIRE THROUGH. ENSURE THAT THREADED DOWN ROD REMAINS 1" LONGER THAN CONDUIT AFTER CUTS.***
6. Feed Lead Wire through the Threaded Down Rod. Screw Threaded Down Rod into Coupling at top of Shade Spider.
7. Slide Conduit over Lead Wires and Threaded Down Rod.
8. Feed Lead Wires through Check Ring and then through Canopy and set on top of Down Rod Assembly. Recessed side of Check Ring should sit onto Down Rod Conduit. Secure Canopy to Assembly with Spider Washer and 1/4 IP Hex Nut.
9. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
10. Lift Assembly up to ceiling, allowing Crossbar Studs to pass through Canopy. Secure with reserved Brass Balls.
11. Install 3 Medium Base 60Watt Bulbs(not included) into Sockets.
12. Lift Diffuser up and into bottom of Shade below Pegs. Secure by feeding Threaded Rod with Finial through center hole and screwing Rod into Coupling at bottom of Light Cluster.
13. Power on and ENJOY!!!

